



**NOTES:**

1. CUT 20mm CONDUIT TO 300mm LENGTH.
2. SCREW CABLE CLAMPS INTO ADAPTORS.
3. THREAD 2 SADDLE CLIPS ONTO CONDUIT.
4. GLUE ADAPTORS TO EACH END OF CONDUIT.

DRAWN	MJM	REV	A						
DATE	9-4-08	DCN							
SCALE	NTS	DATE	9-4-08						



TITLE	PROBE CABLE GRIP
-------	------------------

DRAWING No.	14050
SHEET	1 OF 1